

# ENCON® GRAVITY FED EYEWASH USER NOTICE

Back view (old and new)

1A



2A



Note that the Encon models 01104050 and 01104070 Gravity Fed Eyewash design has been altered to make wall and cart mounting easier. Please be aware of the following:

1. The black mounting bracket (see picture 1A) on the backside of the eyewash has been eliminated. The mounting bracket replacement is an indentation and support rest (see picture 2A, 2B). This design allows the supplied 'J-Hook' to fit up inside this indentation so that the back of the eyewash rests flush against the wall and on this mounting hook.

2. The 'stand-off' pins (see picture 1A, 1B) previously supplied with these models have been discontinued as it was replaced with the addition of molded bumpers (see picture 2A) located on the back wall of the vessel near the bottom of that backside. This will assist in keeping the eyewash in a vertical position against the wall or cart, and give the eyewash an overall lesser profile in the installed, ready to use position.

3. The nozzles (not pictured) have been altered slightly to have differently sized and fewer fluid outlets. The eliminated nozzle ports may still be visible but not functioning on some product.

NOTE: The Safety Equipment Institute (SEI) has tested the gravity fed eyewash unit, with these changes, and certified it to meet the ANSI Z358.1-2009 standard requirements.

Side view (old and new)

1B



2B



*Notice issued 10/04/2010*  
01-1040-50UN